

SYNC Software Update

Step 1 of 4

Prepare to download SYNC software update files to your computer.

1. You will need a USB storage drive to transfer the software update files from your computer to your vehicle.

Make sure the USB storage drive:

- is empty
- can hold at least 32 GB of data
- is not password protected
- is formatted exFAT



2. The download should start automatically after you click "Start Download".



Please do not download this file directly to your USB drive!

If your browser prompts you to do so, choose to "Save" the file to your Desktop or a similar location on your computer's hard drive.

Keep your USB drive nearby. You'll need to use it on Step 2.

Start Download

Need help? 